




3,5
t/h*




236 x 170
A x B mm





170
Ø max.* mm






N° 2



N° 1



P
T
O



●
Benzina + Avviamento elettrico
Petrol + Electric start
Essence + Démarreur électrique
Benzinmotor + Elektroanlasser
Gasolina + Arranque eléctrico
Benzinmotor + Elektrische start
Benzín + Elektrické startování
Benzinski + Elektro start
Benzyna + Rozruch elektryczny
Бензиновым + Электрозпуском

■
Diesel + Avviamento elettrico
Diesel + Electric start
Diesel + Démarreur électrique
Dieselmotor + Elektroanlasser
Diesel + Arranque eléctrico
Diesel + Elektrische start
Diesel + Elektrické startování
Dizel + Elektro start
Diesel + Rozruch elektryczny
Diesel + Электрозпуском

▲
Portato da trattore
Three-point linkage for tractor
Attelage trois-points pour tracteur
Dreipunkt-Anschluss für Traktor
Enganche tres puntos para tractor
Driepunt bevestiging
Veza s tri točke za traktor
Priključak u tri točke
3-punktowy układ zawieszania
Сцепка трехточечнаяЭлектрозпуском



KUBOTA V1505
hp25



L L/h
30 5,2



●
BRIGGS & STRATTON VANGUARD EFI40
hp40



L L/h
30 7,5

											
		C17DK260TRGN		KUBOTA V1505 hp25	☒	☒	3,5	4290/4755 x 1600 x 2000/2710	680	1270 x 750	1235/1365
		C17BB400TRGN		BRIGGS & STRATTON VANGUARD EFI40 hp40	☒	☒	3,5	4290/4755 x 1600 x 2000/2710	680	1270 x 750	1165/1295
		C17DK260TRON		KUBOTA V1505 hp25	☒	☒	3,5	4290/4755 x 1600 x 2000/2710	680	1270 x 750	1235/1365
		C17BB400TRON		BRIGGS & STRATTON VANGUARD EFI40 hp40	☒	☒	3,5	4290/4755 x 1600 x 2000/2710	680	1270 x 750	1165/1295
		C17DK26CN		KUBOTA V1505 hp25	☒	☒	3,5	2835/3285 x 1575 x 2080/2790	760	1270 x 750	1725/1925
		C17BB40CN		BRIGGS & STRATTON VANGUARD EFI40 hp40	☒	☒	3,5	2835/3285 x 1575 x 2080/2790	760	1270 x 750	1665/1865
		C17TPN		Min. hp40 (kW29,9)	☒	☒	3,5	2285/2795 x 1575 x 2030/2740	710	1270 x 750	935/975



* Materiale in entrata - Dato dipendente dal tipo di materiale e dalle condizioni di lavoro. / Input material - Data depending on the kind of material and working conditions. / Matière entrante - Donnée dépendante du type de matériel et des conditions de travail. / Eingangsmaterial - Daten, die von der Art des Materials und den Arbeitsbedingungen abhängen. / Material entrante - Dato que depende del tipo de material y de las condiciones de trabajo. / Ingangsmateriaal - Deze gegevens zijn afhankelijk van het soort materiaal en de werkomstandigheden. / Vstupní materiál - Záleží na druhu materiálu a pracovních podmínkách. / Ulazni materijal - Ovisno o vrsti materijala i uvjetima rada. / Materiał wsadowy - W zależności od rodzaju materiału i warunków eksploatacji. / Входной материал - Это зависит от вида материала и от условий труда.

C17DK260TRGN

KUBOTA V1505 hp25


+ OBS - On Board System



C17TPN

Min. hp40 (kW29,9)

+ OBS - On Board System



C17DK26CN

KUBOTA V1505 hp25

+ OBS - On Board System

