

T13/T20/PTO | Aspirafooglie



150 - 170
m³/min.*



390
Ø mm



200
Ø mm



hp 13



N° 4





**hp 21
/ PTO**




N° 8



~360°



OPTIONAL



Benzina
Petrol
Essence
Benzinmotor
Gasolina
Benzinemotor
Benzín
Benzinski
Benzyna
Бензиновым

Benzina + Avviamento elettrico
Petrol + Electric start
Essence + Démarreur électrique
Benzinmotor + Elektroanlasser
Gasolina + Arranque eléctrico
Benzinemotor + Elektrische start
Benzín + Elektrické startování
Benzinski + Elektro start
Benzyna + Rozruch elektryczny
Бензиновым + Электроразпуском



Portato da trattore
Three-point linkage for tractor
Attelage trois-points pour tracteur
Dreipunkt-Anschluss für Traktor
Enganche tres puntos para tractor
Driepunt bevestiging
Veza s tri točke za traktor
Priključak u tri točke
3-punktowy układ zawieszania
Сцепка трехточечнаяЭлектроразпуском



**HONDA GX390
hp13**




**l l/h
6,1 2,8**



**HONDA GX630
hp21**



**l l/h
10 4,8**

						
	TORNADOBHP13		HONDA GX390 hp13	150	1598 x 638 x 1132	153/165
	TORNADOBHP21		HONDA GX630 hp21	170	1280 x 734 x 1132	195/207
	TORNBH13SOL		HONDA GX390 hp13	150	1210 x 1100 x 2500	219/234
	TORNBH21SOL		HONDA GX630 hp21	170	1310 x 1100 x 2500	265/280
	TORNBH13TRG		HONDA GX390 hp13	150	2450 x 1286 x 2296	290/380
	TORNBH21TRG		HONDA GX630 hp21	170	2450 x 1286 x 2296	340/430
	TORNBH13TRO		HONDA GX390 hp13	150	2450 x 1286 x 2296	290/380
	TORNBH21TRO		HONDA GX630 hp21	170	2450 x 1286 x 2296	340/430
	TORNAOPTO		Min. hp13 (kW9,6)	170	938 x 756 x 1626	225/237



* Materiale in entrata - Dato dipendente dal tipo di materiale e dalle condizioni di lavoro. / Input material - Data depending on the kind of material and working conditions. / Matière entrante - Donnée dépendante du type de matériel et des conditions de travail. / Eingangsmaterial - Daten, die von der Art des Materials und den Arbeitsbedingungen abhängen. / Material entrante - Dato que depende del tipo de material y de las condiciones de trabajo. / Ingangsmateriaal - Deze gegevens zijn afhankelijk van het soort materiaal en de werkomstandigheden. / Vstupní materiál - Záleží na druhu materiálu a pracovních podmínkách. / Ulazni materijal - Ovisno o vrsti materijala i uvjetima rada. / Materiał wsadowy - W zależności od rodzaju materiału i warunków eksploatacji. / Входной материал - Это зависит от вида материала и от условий труда.


TORNBH13SOL

HONDA GX390 hp13



TORNADOBHP13

HONDA GX390 hp13



TORNAOPTO

Min. hp13 (kW9,6)



TORNBH13TRG

HONDA GX390 hp13



TORNBH21TRO

HONDA GX630 hp21

